

Safety information

IT IS IMPORTANT THAT YOU READ THE SAFETY AND PRODUCT INFORMATION BOOKLET (INCLUDED) PRIOR TO USING YOUR BLACKBERRY® DEVICE. It contains essential safety information related to your device.

More tips, interactive demos, and videos are online! For more info, go to www.blackberry.com/ gettingstarted.



(1) Insert the SIM card and battery









low battery power







③ Insert a media card

You can use a media card to store more media files. A media card might already be inserted. To insert To remove

2



4 Set up your device

Get started quickly with Setup! Setup should appear automatically, but if it doesn't, on the Home screen, click the **Setup** icon.



To see a video, on the Home screen, click the **Setup** icon and see the **Help & Tutorials** section.

5 Set up your email

- If you're is Setup already, click the **Email Accounts** icon. If you aren't in Setup, on the Home screen, click the **Setup** icon > **Email Accounts** icon.
 I follow the screens to set up your email address. When your email address is set up correctly, you receive a confirmation message. To see your email, on the Home screen, click the **Messages** icon.
 Note: In some cases, you might see the following options. If so, select one of the options.
- Internet Mail Account: Use this option to associate your BlackBerry[®] device with one or more existing email accounts (for example, Windows Live[™] Hotmail[®]) or to create a new email address for your device.
- accounts for example, windows use "notional" for to treate a new ennai adures for your bevice. **Cherprise Account:** If your administrator gave you an enterprise activation password, use this option to associate your device with your work enail account for example, Windows Live" Notmain 10° or a new enail address for your device, and do not see this option, contact your administrator or wireless service provider.

Need help setting up your email?

- On the know screen, click the Setup ion. On the Email Accounts screen, verify that your email address information is correct.
 Verify with your wrieless service provider that your email account type is supported.
 Verify that you are wellched devices correctly.
 For more info about setting up an email address, go to www.blackberry.com/doc/s/snartphones and click the link below Email Setup.
- - Connect your new device to your computer.
 In the dialog box that appears, click **Copy data and settings from another device** and follow the prompts.

2. If you have a SIM card, put it into your new device.

Switch devices

To switch from a BlackBerry[®] device that has an existing email address and to move your data to a ne BlackBerry device, do the following: 1. On your computer, open BlackBerry[®] Desktop Software 6.0. To get the latest software, go to

5. On your new device, on the Setup screen that appears, click the Email Accounts icon and follow the prompts. If you decline any of the prompts, email won't be sent to your new device. If you're selling or buying a previously owned BlackBerry device that operates on CDMA networks, contact your wireless service provider to switch devices.



111





Pop-up menu

pplications		Status indicators		Quick tips	
et started with some of these great applications. Messages	Options Set your device options. You can find more options in each application menu.	Home screen	the priority ★ message not sent	These tips are for when you type using SureType® technology. For multi-tap typing tips, see the user guide for your BlackBerry® device.	Change the volume Press the Volume keys on the rig side of your BlackBerry® device
Send emails, PIN messages, and more. Text Messages Send text messages.	Manage Connections Set up wireless connections, such as a Bluetooth® connection.	Image: system of the system Image: system of the system Image: system of the system of the system Image: system of the system Image: system of the system of the system Image: system of the system Image: system of the system of the system Image: system of the system Image: system of the system of the system Image: system of the system Image: system of the system of the system Image: system of the system Image: system of the system of the system Image: system of the system Image: system of the system of the system Image: system of the system Image: system of the system of the system Image: system of the system Image: system of the system Image: system of the system Image: system of the system Image: system Image: system Image: system Image: system Image: system Image: system Image: system	draft est meting invite Phone	Typing Insert a period Press the La key twice	Mute a call Press the VII key on the top your device Pictures Zoom in to a Click the trackpad
Browser Browse websites.	Find answers here or click Help in a menu.	Calendar Count Social feeds	V missed call V received call	Capitalize a Press the 🐼 A key and the letter key Type a number Press and hold a key until the	stored picture For more tips, on the Home screen, click the Setu
Media See saved pictures, play songs, and more.	To show or hide an icon, highlight the icon using the trackpad. Press the 😯 key > Show All or Hide.	missed call count sending or receiving data	voice mail message	number appears icon and see the Help & Tutorials see: Type a symbol Press the gym key important: When you use your device, take freque means and you body, sto Mose to the Press the Paths key	icon and see the Help & Tutorials section. Important: When you use your device, take frequent breaks. If yo
Camera (if supported) Take pictures.		Wi-Fi® turned on A roaming Messages			experience discomfort in any part of your body, stop using your o immediately. If the discomfort persists, consult a physician.
Instant Messaging Chat with friends or colleagues.		unopened 📄 opened		top of the message inbox Phone	

Send an email

 On the Home screen, click the Message
 Press the second secon In the **To** field, type an email address.
 Type a message.
 Press the figure key > Send.

- Change your ring tone 1. From the Home screen, press the key. 2. Press the key > Phone Ring Tones.
- In the Ring Tone field, click a preloaded ring tone or click All Music or All Alerts.

4. Press the 🗱 key > Save.

BlackBerry Messenger

Stay connected with family and friends who also use BlackBerry® Messenger. Send instant messages, update your status, and create groups so that you can share pictures, appointments, and more!

Add a contact using a barcode On the Home screen, click the BlackBerry Messenger icon.

- Messenger ILUI. 2. Press the **[B2]** key > Invite Contact > Invite by scanning a PIN barcode. 3. Hold your device so that all four corners of the contact's barcode appear on your screen and you hear a beep. To show your barcode, click your display name. Click Show.

Pair with a Bluetooth enabled device

You must pair your BlackBerry[®] device with the Bluetooth[®] enabled device before you can connect to it. Fo information about preparing a Bluetooth enabled device for pairing, see the instructions for that device. On the Home screen, click the connections area at the top of the screen, or click the Manage Connections

- 2. In the Setup, Services, and Options section, click Bluetooth Connections
- If necessary, change the Bluetooth field to On.
 Click Add New Device > Search.
 Click the Bluetooth enabled device.

- 6. If necessary, do one of the following:

• If the Bluetooth enabled device has a keyboard, type a pairing passkey of your own choosing on both devices.

Browse websites

1. On the Home screen, click the Browser icon.
2. Type a web address. If an address bar doesn't appear, press the **GB** key of Col the trackpad.
3. Press the **GB** key, or click the trackpad.
BackBerry⁴ device might have multiple browsers, contact or wire leash suscepted with each browser, contact or just wired provide provide.

Tabbed browsing With the new tabbed browsing feature, you can easily switch between websites that you have open. For more info, on the Home screen, click the **Help** icon and search for tabbed browsing.

Take a picture

On the Home screen, click the **Camera** icon.
 To zoom in to or out from a subject, on the trackpad, slide your finger up or down.
 Click the trackpad.

Record a video

- On the Home screen, click the Media icon > Video Camera icon.

 Click the trackpad.
 To pause recording, click the trackpad again. Depending on your BlackBerry[®] device model, the camera or video camera might not be supported or some camera or video camera features might not be available.

? Download apps and themes Connect using Wi-Fi Change your wallpaper Connect to your computer Sync your media files Need more help? On the Home screen, click the connections area at the top of the screen, or click the Manage Connections icon. In the Setup, Services, and Options section, click Set Up WH-F Network. If prompted, click Turn on WI-FI. You can use BlackBerry[®] Desktop Software 6.0 to back up and restore BlackBerry device data and sync calendar appointments, music, pictures, and more between your device and computer. www.blackberry.com/gettingstarted: Find getting started information. 'Our wireless service provider's web site: Find information about your wireless network or wireless service plan. Connect your BlackBerry[®] device to your computer. 1. From the Home screen, press the 🗱 key. You can download applications, themes, and ring tones from your wireless service provider's website (if available) or from the BlackBerry App World™ storefront. Click Options > Change Walpaper. Click Options > Change Walpaper. To take a picture, click Camera. Click the camera icon. To use an existing picture, click Camera Pictures, Picture Library, or Walpaper. Click a picture. On your computer, open the BlackBerry[®] Desktop Software. **F** • If you're using a Windows® computer, click Music, Pictures, or Videos. <u>Sii</u> 📕 💿 🕒 CAUTION: Use only those accessories approved by Research In Motion. Using any accessories not approved by RIM for use with this particular device model might invalidate any approval or warranty applicable to the device, might result in the non-operation of the device, and might be dangerous. If you want to connect to a public hotspot or Wi-Fi® network that does not require a password, select the Show Open networks only check box. Click the Wi-Fi network that you want to connect to. If you're using a Mac computer, in the Media section in the left pane, click Music. Mac users can sync only music. 3. Press the Herein and the second seco To download the BlackBerry Desktop Software, go to For more info, see the Help in the BlackBerry Desktop Software. Additional data service provide