







## Navigation and Function Tips

<b>To:</b> Open a menu in any application,	<b>Do:</b> press the  key.
Access options and available actions,	press the  key.
Close a menu or move back a screen,	press the  key.
Return to the Home screen,	press the  key.
Show a description on the shortcut bar,	touch and hold the shortcut.
Hide the keyboard,	slide your finger down.

## Picture Tips

<b>To:</b> Take a picture,	<b>Do:</b> press the <b>Right Convenience</b> key.
Lock the focus on a subject before you take a picture,	press the <b>Right Convenience</b> key halfway.

## Music Tips

<b>To:</b> Pause a song or video,	<b>Do:</b> press the  key.
Resume playing a song or video,	press the  key again.

For more actions, see the setup wizard on your BlackBerry® smartphone.

For more information, please visit [www.blackberry.com/storm](http://www.blackberry.com/storm) **BlackBerry Storm**.  
©2008 Research In Motion Limited. All Rights Reserved. BlackBerry®, RIM®, Research In Motion®, SureType® and related trademarks, names and logos are the property of Research In Motion Limited and are registered and/or used in the U.S. and countries around the world. MKT-22354-001

# BlackBerry Storm smartphone

## Tips

[www.blackberry.com/storm/tips](http://www.blackberry.com/storm/tips)



**BlackBerry Storm**

# BlackBerry® Storm™ smartphone

## Tips



## Getting Started

To set up the BlackBerry® Storm™ smartphone, complete the following tasks. You can also see the **Getting Started Guide** (comes with the smartphone) or click **Help** on the device for step-by-step instructions.

- Insert the SIM card.
- Insert the battery.
- Charge the battery.
- Complete the setup wizard.

## Touchscreen Tips

To:	Do:
Select an item,	click (press) the item.
Highlight an item or place the cursor,	touch the screen lightly.
Scroll down,	touch and hold near the bottom of the screen.
Scroll up,	touch and hold near the top of the screen.
Move down a screen,	slide your finger up quickly.
Move up a screen,	slide your finger down quickly.
Move to the next item,	slide your finger to the left quickly.
Move to the previous item,	slide your finger to the right quickly.