

**PORSCHE DESIGN
SMARTPHONE
P'9981**

Start Here



WELCOME TO YOUR NEW SMARTPHONE

- Lock the screen**
- Notification LED**
- Touch screen**
- Volume up**
- Mute**
- Volume down**
- Headset jack**
- USB port**
- Trackpad**
Move around the screen
Select an item
- Menu key**
Make or answer a call
- Send key**
- Type the other character on a key**
- Capitalize letters**
Type Symbols
- Escape key**
Move back a screen
- End/Power key**
Hold to turn on or turn off
End a call
Return to Home screen
- Enter**
- Microphone**
(Do not cover)
- Convenience key**
Take a picture
You can customize this key

EXPLORE THE HOME SCREEN

- Battery power level**
- Change your ringtone or alerts**
See upcoming appointments, new messages, and other notifications
- Notification view**
- Navigation bar**
Tap to see more icons
Slide left or right for more panels
- Wireless indicators**
Tap to manage wireless connections, Wi-Fi®, Bluetooth® technology, or alarm clock
- Search**
Search your entire smartphone, including help, messages, music, the Internet, and more

You can move and hide icons. Press and hold an icon and tap **Move or Hide**.

Only use authorized BlackBerry accessories. This documentation is provided "as is" and without warranties, endorsement, guarantee, representation or warranty, or liability of any kind by Research In Motion Limited and its affiliated companies, all of which are expressly disclaimed to the maximum extent permitted by applicable law in your jurisdiction.

©2011 Research In Motion Limited. All rights reserved. BlackBerry®, RIM®, Research In Motion® and related trademarks, names and logos are the property of Research In Motion Limited and are registered and/or used in the U.S. and countries around the world. iOS is a trademark of Apple Inc., Bluetooth is a trademark of Bluetooth SIG, Porsche, Porsche Design and the Porsche Design logo are trademarks of Dr. Ing. h. c. F. Porsche Aktiengesellschaft, Windows is a trademark of Microsoft Corporation, Wi-Fi is a trademark of the Wi-Fi Alliance. All other trademarks are the property of their respective owners.

MSI-4001-0106v002 (RIM)TFC-001 (SAP) 174125-10401371-001 | 07/10/10 1027 108

BlackBerry

SAFETY INFORMATION

IT IS IMPORTANT THAT YOU READ THE SAFETY AND PRODUCT INFORMATION BOOKLET (INCLUDED) PRIOR TO USING YOUR BLACKBERRY® SMARTPHONE. It contains essential safety information related to your smartphone.

MORE GETTING STARTED INFORMATION

For videos, BlackBerry® Answers, and more, go to www.blackberry.com/gettingstarted.

① INSERT THE SIM CARD



To remove the battery door, pull up the bottom of the battery door.

② INSERT THE BATTERY



A media card is already inserted and is located above the battery. To remove the media card, pull the card out of the slot.

③ SET UP YOUR SMARTPHONE



1. If prompted, set up your BlackBerry® ID.
 2. Get started quickly with Setup!
- If Setup doesn't start automatically, on the Home screen, tap the **Setup** icon.

④ SET UP YOUR EMAIL



1. On the Home screen, tap the **Setup** icon > **Email Accounts** icon.
2. Follow the instructions to set up your email address.

When your email address is set up correctly, you receive a confirmation email. To see your email, on the Home screen, tap the **Messages** icon.
Data plan required.

IMPORT YOUR CONTACTS

You can import your contacts from a SIM card or by using the BlackBerry® Desktop Software. For information about the BlackBerry Desktop Software, see the "Connecting to your computer" section in this guide.

If you have a SIM card, do the following:

1. On the Home screen, tap the **Setup** icon > **SIM Contacts Sync** icon.
2. Follow the instructions on the screen.

Features not supported by all wireless service providers.

SWITCH SMARTPHONES

To move data from a previous BlackBerry® smartphone, do the following:

1. On your computer, open the BlackBerry® Desktop Software. To get the latest software, go to www.blackberry.com/desktopsoftware.
2. Connect your new smartphone to your computer.
3. Click **Copy data and settings from another device** and follow the prompts.
4. If necessary, on your new smartphone, tap the **Setup** icon > **Email Accounts** icon and follow the prompts.

LOCK YOUR SCREEN


To lock your screen, press the **Lock** key on the top of your P9981 smartphone.


SET A PASSWORD


1. On the Home screen, tap the **Setup** icon > **Password** icon.
2. Select **Enable** > tap **Set Password**, and follow the prompts.


To lock your smartphone, on the Home screen, tap the **Password Lock** icon. Record your password for future use.


APPLICATIONS


 **Messages**
Send emails and other messages.


 **Text Messages**
Send text messages.

 **Browser**
Browse websites.


 **Media**
See saved pictures, play songs, and more.

 **BlackBerry Messenger**
Chat with friends or colleagues.

 **Camera**
Take pictures.

 **Options**
Set options. You can find more options in each application menu.











 **Manage Connections**
Set up wireless connections, such as a Bluetooth® connection.

 **Help**
Find the user guide here or tap **Help** in a menu.









For more icons, see the *Icon Guide* at docs.blackberry.com/icons/70.

STATUS INDICATORS

Home screen

| | |
|--|---|
|  New notification |  Alarm set |
|  Unopened message count |  BlackBerry® Messenger |
|  Social feeds |  Roaming |
|  BlackBerry App World™ notification |  Sending or receiving data |
|  Wi-Fi® turned on |  Bluetooth® technology turned on |

Messages

| | |
|--|--|
|  Unopened |  Opened |
|  Text message |  Sent message |
|  Attachment |  Meeting invite |
|  Message is sending |  Message not sent |

Phone

| | |
|---|--|
|  Missed call |  Received call |
|  Placed call |  Voice mail message |

MESSAGES



Open a pop-up menu

Touch and hold a message to open a pop-up menu of common actions

Use the pop-up menu to delete, compose, or forward messages, and more

See navigation options
Tap the Date bar

Open a message
Tap a message or click the trackpad


Send a text message

1. On the Home screen, tap the **Text Messages** icon.
2. Press the **PF1** key > **Compose Text Message**.
3. In the **To** field, type the contact information.
4. Type a message.
5. Press the **PF2** key > **Send**.
To insert a period while you're typing, press the **Space** key twice.

Extra fees might apply.

To view all your messages, on the Home screen, tap the **Messages** icon.

BLACKBERRY MESSENGER



See your profile and pin, or change your status

See contacts

Create a new group

Open a chat

Touch and hold to open a pop-up menu of common actions

Chat with your friends virtually anywhere, anytime!

Add a contact using a barcode

1. On the Home screen, tap the **BlackBerry Messenger** icon.
2. Press the **PF2** key > **Invite to BBM** > **Scan a PIN barcode**.
3. Hold your BlackBerry® smartphone so that all four corners of the contact's barcode appear on your screen and you hear a beep.
Data plan required.

PHONE



Dial a number

Call log

Open the menu
Press and hold the 1 key

Check your voice mail
Press and hold the 1 key

Set up a speed dial number
Press and hold a key

Volume/Mute keys

View your contacts or call log

End a call

Delete


Speakerphone

To make or answer a call, or to open the Phone application, press the **Call** key.

Change your ring tone

1. On the Home screen, tap the **Setup** icon > **Ring Tones** icon.
2. In the **Ring Tone** field, tap a preloaded ring tone or tap **All Music** or **All Alerts**.
3. Press the **PF2** key > **Save**.

BROWSER



Type a web address
Touch and hold the screen

Open a pop-up menu of common actions
Touch and hold the screen

Open tab view
Touch the **Tab** icon

Open your bookmarks and history
Touch the **Bookmarks** icon


Zoom/pan
To zoom, slide your finger and thumb together or apart, or click the trackpad.
To pan a zoomed page, slide your finger on the screen or trackpad.

Close the selected tab
Touch the **X** icon

Open a webpage in a new tab
Touch the **Open in New Tab** icon

Data plan required.

CAMERA



Zoom in or out
Slide your finger up or down on the screen or trackpad

Add your location to the picture
Touch the **Location** icon


View pictures
Touch the **Gallery** icon

Change settings for different scenes
Touch the **Settings** icon

Record a video

1. On the Home screen, tap the **Media** icon > **Video Camera** icon.
2. Tap the **Record** icon.
3. To pause recording, tap the **Stop** icon.

PICTURES



Zoom/pan
To zoom, slide your finger and thumb together or apart, or click the trackpad.
To pan a zoomed picture, slide your finger on the screen or trackpad.

Open a pop-up menu
Touch and hold the screen

Scroll through pictures
When zoomed out, slide your finger left or right quickly on the screen or trackpad

Change your wallpaper

1. On the Home screen, tap the **Setup** icon > **Wallpaper** icon.
2. Take a picture or use an existing picture.
3. Press the **Set** key > **Set As Wallpaper**.
4. Press the **Home** key to return to the Home screen.

To see your pictures, tap the **Media** icon > **Pictures**.

BLACKBERRY APP WORLD

Click an app to download or buy it

Search by category

See the top 25 apps

Search

Manage your apps

Downloaded apps appear on the Home screen. Download games, apps, and more! Go to www.blackberry.com/appworld. Data plan required.

WI-FI AND BLUETOOTH

12:21

Wireless indicators

Message Connections

Mobile Network

Wi-Fi

Bluetooth

NFC

Turn off connections (airplane mode)

Turn on Mobile Network, Wi-Fi, Bluetooth technology, and NFC

Let's you read smart tags and more

To manage wireless connections, tap the **Manage Connections** icon.

- To pair with a Bluetooth enabled device, tap **Networks and Connections**.
- To connect to a Wi-Fi network, tap **Wi-Fi Network**.

CUT, COPY, AND PASTE

Simultaneously touch the beginning and end of the text, then press the **key** > **Cut** or **Copy**

To paste the text, press the **key** > **Paste**

Open a pop-up menu

Touch and hold the screen or press and hold the trackpad

To see a video, tap the **Setup** icon > **Tutorials** > **Edit Text**.

CONNECTING TO YOUR COMPUTER

You can use BlackBerry® Desktop Software to do the following:

- Sync your contacts, music, pictures, and more
- Back up and restore smartphone data
- Update your software

To download the BlackBerry Desktop Software, go to www.blackberry.com/desktopsoftware.

SYNC YOUR MEDIA FILES

- Connect your BlackBerry® smartphone to your computer.
- On your computer, open the BlackBerry® Desktop Software.
 - If you're using a Windows® computer, click **Music, Pictures, or Videos**.
 - If you're using a Mac computer, in the **Media** section in the left pane, click **Music**.

For more information, see the Help in the BlackBerry Desktop Software.

NEED MORE HELP?

- Find help from the Home screen—just tap the **Q** icon and start typing!
- For tutorials, tap the **Setup** icon > **Tutorials**.
- www.blackberry.com/gettingstarted: Find getting started information.
- www.blackberry.com/go/docs: Find the complete user guide.
- Find information about your wireless service plan on your wireless service provider's website.

To view the Declaration of Conformity made under Directive 1999/5/EC (R&TTE 2002), go to www.blackberry.com/go/declarationofconformity.